


GOLOUR TV SERVICE MANUAL

CAUTION

BEFORE SERVICING THE CHASSIS, READ THE "SAFETY PRECAUTIONS" IN THIS MANUAL



CHASSIS: NC-36A

MODEL: CN-14A80


GCT1304M(CN-14A82)


GCT1354M(CN-14A84)


CN-20A80


GCT1904N(CN-20A82)

















MARNING : BEFORE SERVICING THIS CHASSIS, READ THE 'X-RAY RADIATION PRECAUTION. 'SAFETY PRECAUTION' AND PRODUCT SAFETY NOTICE IN THIS MANUAL

carefully the PRODUCT SAFETY NOTICE in this manual. Do not degrade the safety be replaced only which types identical to those in the original circuit or specified in the parts list. Before replacing any of these components, read marks in the schematic diagram and the parts list designate CAUTION : The $ilde{m{A}}$ marks in the schematic diagram and the parts list designonents which have special characteristics for safety, and should of the receiver through improper servicing.

AVIS SUR LA SECURITE DU PRODUCT

recommandé de lire le manuel de service. No maitraitez pas le recepteur Les pièces de la partie ombrée possdent d'importantes caratèristiques speciales par rapport à la sécurité et avant de les remplacer, il est car vous pourriez en endommager ie système securitaire.

- 1. Resistance is shown in ohm. K=1.000 N=1.000.000 G. Capacitors are shown in uF otherwise noted: P = 3. Unless otherwise listed. All indictor willow
- Capacitors are shown in uF otherwise noted: P = uu
- Unless otherwise listed. all inductor values more than 1 are expressed in uk, and the values less than 1 in H.
 - Voltages are measured DVM from point indicated to chassis ground using color bar signal with all controls at normal.
- Waveforms are measured with synchroscope from point indicated to chassis ground. Using color bar with all controls at normal.
- May choose anyone, since listed following semiconductors have same characteristics

